

Dash Gauges

DR. E. BROWN ENTERPRISES
24 HR. SCIENTIFIC SERVICES



	Press	Hold
Time Travel button	Trigger Time Travel	Unlock gauges hardware selection in Config Portal
Button 1	Re-activate or connect WiFi	Say current IP address

Commands from TCD/HA	
Refill	009
Set full percentage of Primary gauge	91xx
Set full percentage of Percent Power gauge	94xx
Set full percentage of Roentgens gauge	97xx
Select volume level (00 - 19)	93xx
Music Player : Play / Stop	9005
Music Player : Previous Song	9002
Music Player : Next Song	9008
Music Player : Set folder number	905x
Music Player : Shuffle off	9222
Music Player : Shuffle on	9555
Music Player : Go to song 000	9888
Music Player : Go to song xxx	9888xxx
Play "keyX.mp3" (X = 1, 3, 4, 6, 7, 9)	900x
Play "keyX.mp3" (X = 1 - 9)	950x
Say current IP address	9090
Restart*	9064738
Delete static IP address*	9123456
Unlock gauges hardware selection in CP	9317931

Control through TCD requires BTTFN connection.

* Not through HA/MQTT