

Dash Gauges

DR. E. BROWN ENTERPRISES
24 HR. SCIENTIFIC SERVICES



	Press	Hold
Time Travel button	Trigger Time Travel	Unlock gauges hardware selection in Config Portal
Button 1	Re-activate or connect WiFi	Say current IP address

Commands from TCD	
Refill	009
Set full percentage of Primary gauge	91xx
Set full percentage of Percent Power gauge	94xx
Set full percentage of Roentgens gauge	97xx
Select volume level (00 - 19)	93xx
Music Player : Play / Stop	9005
Music Player : Previous Song	9002
Music Player : Next Song	9008
Music Player : Set folder number	905x
Music Player : Shuffle off	9222
Music Player : Shuffle on	9555
Music Player : Go to song 000	9888
Music Player : Go to song xxx	9888xxx
Play "keyX.mp3" (X = 1, 3, 4, 6, 7, 9)	900x
Play "keyX.mp3" (X = 1 - 9)	950x
Say current IP address	9090
Restart	9064738
Delete static IP address	9123456
Unlock gauges hardware selection in CP	9317931

Control through TCD requires BTTFN connection.