

# Dash Gauges

DR. E. BROWN ENTERPRISES  
24 HR. SCIENTIFIC SERVICES



TCD commands	
Refill	009
Set full percentage of Primary gauge	91xx
Set full percentage of Percent Power gauge	94xx
Set full percentage of Roentgens gauge	97xx
Select volume level (00 - 19)	93xx
<b>Music Player</b> : Play / Stop	9005
<b>Music Player</b> : Previous Song	9002
<b>Music Player</b> : Next Song	9008
<b>Music Player</b> : Set folder number	905x
<b>Music Player</b> : Shuffle off	9222
<b>Music Player</b> : Shuffle on	9555
<b>Music Player</b> : Go to song 000	9888
<b>Music Player</b> : Go to song xxx	9888xxx
Play "keyX.mp3" on SD card (X = 1, 3, 4, 6, 7, 9)	900x
Say current IP address	9090
Restart	9064738
Delete static IP address	9123456
Unlock gauges hardware selection in CP	9317931

Control through TCD requires BTTFN connection.

	Press	Hold
Time Travel button	Trigger Time Travel	Permit hardware configuration in Config Portal
Button 1	<b>Re-activate</b> or <b>connect</b> WiFi	Say current IP address